

# Glutamate Dehydrogenase (GDH) Activity Colorimetric Assay Kit

(Catalog #BN00948; 100 reactions; Store kit at -20 °C)

## I. Introduction:

Glutamate dehydrogenase (GDH) is an enzyme that converts glutamate to  $\alpha$ -Ketoglutarate, and vice versa. It represents a key link between catabolic and metabolic pathways, and is therefore ubiquitous in eukaryotes. Assay Genie's GDH Assay Kit provides a convenient tool for sensitive detection of GDH in a variety of samples. GDH in sample will consume glutamate as a specific substrate and generate NADH stoichiometrically, resulting in a proportional color development. The GDH activity is easily quantified colorimetrically ( $\lambda = 450 \text{ nm}$ ). This assay detects GDH activity as low as 0.01mU in serum or tissue and cell extracts.

## II. Kit Contents:

Components	BN00948	Cap Code	Part Number
GDH Assay Buffer	25 ml	WM	BN00948-1
Glutamate (2 M)	1.0 ml	Blue	BN00948-2
GDH Developer (lyophilized)	1 vial	Red	BN00948-3
GDH Positive Control (lyophilized)	1 vial	Green	BN00948-4
NADH (0.5 $\mu\text{mol}$ ; lyophilized)	1 vial	Yellow	BN00948-5

## III. Storage and Handling:

Store the kit at -20°C, protect from light. Allow Assay Buffer to warm to room temperature before use. Briefly centrifuge vials before opening. Read the entire protocol before performing the assay.

## IV. Reagent Reconstitution and General Consideration:

- Ensure that the Assay Buffer is at room temperature before use.
- Reconstitute the Glutamate Dehydrogenase (GDH Positive Control) with 220  $\mu\text{l}$  Assay Buffer. Keep the GDH Positive Control on ice during the preparation and protect from light. Aliquot and store -20°C.
- Reconstitute the GDH developer with 0.9 ml of ddH<sub>2</sub>O. Pipette up and down several times to completely dissolve the pellet into solution (DO NOT VORTEX).
- Reconstitute the NADH with 50  $\mu\text{l}$  ddH<sub>2</sub>O to generate a 10 mM NADH stock solution.
- The GDH Positive Control and GDH Developer are stable for up to 2 months at -20°C after reconstitution or freeze-thaw cycles (< 5 times). Reconstituted NADH (10 mM) and the supplied Glutamate (2 M) solution are stable for up to 6 months at -20°C.

## V. Glutamate Dehydrogenase Assay Protocol:

- 1. NADH Standard Curve:** Dilute 10  $\mu\text{l}$  of the 10 mM NADH stock solution with 90  $\mu\text{l}$  of GDH Assay Buffer to generate a 1 mM NADH standard. Add 0, 2, 4, 6, 8, 10  $\mu\text{l}$  of the 1 mM NADH standard into a 96-well plate to generate 0, 2, 4, 6, 8, 10 nmol/well standard. Adjust the final volume to 50  $\mu\text{l}$  with Assay Buffer.
- 2. Sample Preparations:** Tissues (50 mg) or cells ( $1 \times 10^6$ ) can be homogenized in ~ 200  $\mu\text{l}$  ice-cold Assay Buffer then centrifuged (13,000 x g for 10 min.) to remove insoluble material. Add test sample into 96-well plate, bring volume to 50  $\mu\text{l}$ /well with Assay Buffer. 5 - 50  $\mu\text{l}$  serum

samples can be directly diluted in the Assay Buffer. For the positive control (optional), add 2  $\mu\text{l}$  positive control solution to wells and adjust to a final volume of 50  $\mu\text{l}$  with Assay Buffer.

- 3. Reaction Mix:** Mix enough reagents for the number of assays to be performed. For each well, prepare a Reaction Mix (100  $\mu\text{l}$ ) containing:

82  $\mu\text{l}$  Assay Buffer  
8  $\mu\text{l}$  GDH Developer  
10  $\mu\text{l}$  Glutamate (2 M)

Add 100  $\mu\text{l}$  of the Reaction Mix to each well containing the test samples, positive controls and standards. Mix well. For the samples and positive controls, incubate the mix for 3 min at 37°C, then measure OD at 450 nm in a microplate reader (A0), incubate for another 30 min. to 2 hrs at 37°C to measure OD at 450 nm again (A1); incubation times will depend on the GDH activity in the samples. We recommend measuring the OD in a kinetic method (preferably every 3 – 5 min.) and choose the period of linear range (e.g. **A<sub>n</sub>** to **A<sub>n+1</sub>**) to calculate the GDH activity of the samples.

- 4. Calculation:** Plot Glutamate Standard Curve. Apply  $\Delta \text{OD} = A_1 - A_0$  (or **A<sub>n+1</sub>** - **A<sub>n</sub>**) to the Glutamate Standard Curve to get B nmol of NADH produced by GDH in the given time.


$$\text{GDH Activity} = \frac{B}{T \times V} \times \text{Sample Dilution Factor} = \text{nmol/min/ml} = \text{mU/ml}$$

Where: **B** is the NADH amount from Standard Curve (in nmol).

**T** is the time incubated (in min).

**V** is the sample volume added into the reaction well (in ml).

**Unit Definition:** One unit is the amount of enzyme that will generate 1.0  $\mu\text{mol}$  of NADH per min. at pH 7.6 and 37°C.



\*Sample 01: Bovine Liver extraction (2  $\mu\text{g}$  protein), Sample 02: 5  $\mu\text{l}$  Rabbit serum

**FOR RESEARCH USE ONLY! Not to be used on humans.**

## GENERAL TROUBLESHOOTING GUIDE:

Problems	Cause	Solution
Assay not working	<ul style="list-style-type: none"> <li>• Use of ice-cold assay buffer</li> <li>• Omission of a step in the protocol</li> <li>• Plate read at incorrect wavelength</li> <li>• Use of a different 96-well plate</li> </ul>	<ul style="list-style-type: none"> <li>• Assay buffer must be at room temperature</li> <li>• Refer and follow the data sheet precisely</li> <li>• Check the wavelength in the data sheet and the filter settings of the instrument</li> <li>• Fluorescence: Black plates (clear bottoms) ; Luminescence: White plates ; Colorimeters: Clear plates</li> </ul>
Samples with erratic readings	<ul style="list-style-type: none"> <li>• Use of an incompatible sample type</li> <li>• Samples prepared in a different buffer</li> <li>• Cell/ tissue samples were not completely homogenized</li> <li>• Samples used after multiple free-thaw cycles</li> <li>• Presence of interfering substance in the sample</li> <li>• Use of old or inappropriately stored samples</li> </ul>	<ul style="list-style-type: none"> <li>• Refer data sheet for details about incompatible samples</li> <li>• Use the assay buffer provided in the kit or refer data sheet for instructions</li> <li>• Use Dounce homogenizer (increase the number of strokes); observe for lysis under microscope</li> <li>• Aliquot and freeze samples if needed to use multiple times</li> <li>• Troubleshoot if needed</li> <li>• Use fresh samples or store at correct temperatures until use</li> </ul>
Lower/ Higher readings in Samples and Standards	<ul style="list-style-type: none"> <li>• Improperly thawed components</li> <li>• Use of expired kit or improperly stored reagents</li> <li>• Allowing the reagents to sit for extended times on ice</li> <li>• Incorrect incubation times or temperatures</li> <li>• Incorrect volumes used</li> </ul>	<ul style="list-style-type: none"> <li>• Thaw all components completely and mix gently before use</li> <li>• Always check the expiry date and store the components appropriately</li> <li>• Always thaw and prepare fresh reaction mix before use</li> <li>• Refer datasheet &amp; verify correct incubation times and temperatures</li> <li>• Use calibrated pipettes and aliquot correctly</li> </ul>
Readings do not follow a linear pattern for Standard curve	<ul style="list-style-type: none"> <li>• Use of partially thawed components</li> <li>• Pipetting errors in the standard</li> <li>• Pipetting errors in the reaction mix</li> <li>• Air bubbles formed in well</li> <li>• Standard stock is at an incorrect concentration</li> <li>• Calculation errors</li> <li>• Substituting reagents from older kits/ lots</li> </ul>	<ul style="list-style-type: none"> <li>• Thaw and resuspend all components before preparing the reaction mix</li> <li>• Avoid pipetting small volumes</li> <li>• Prepare a master reaction mix whenever possible</li> <li>• Pipette gently against the wall of the tubes</li> <li>• Always refer the dilutions in the data sheet</li> <li>• Recheck calculations after referring the data sheet</li> <li>• Use fresh components from the same kit</li> </ul>
Unanticipated results	<ul style="list-style-type: none"> <li>• Measured at incorrect wavelength</li> <li>• Samples contain interfering substances</li> <li>• Use of incompatible sample type</li> <li>• Sample readings above/below the linear range</li> </ul>	<ul style="list-style-type: none"> <li>• Check the equipment and the filter setting</li> <li>• Troubleshoot if it interferes with the kit</li> <li>• Refer data sheet to check if sample is compatible with the kit or optimization is needed</li> <li>• Concentrate/ Dilute sample so as to be in the linear range</li> </ul>
<p><b>Note:</b> The most probable list of causes is under each problem section. Causes/ Solutions may overlap with other problems.</p>		