



Technical Manual

ENR (Enrofloxacin) ELISA Kit

- Catalogue Code: FSES0024
- Competitive ELISA Kit
- Research Use Only

Contents

1. Key features and Sample Types	3
2. Storage	3
3. Test Principle.....	3
4. Kit Contents.....	4
5. Experimental Preparation	5
6. Assay Procedure.....	7
7. Data Analysis.....	7
8. Notes.....	8

1. Key features and Sample Types

Sensitivity:

0.1 ppb (ng/mL)

Assay Procedure:

25°C, 45 min~15min

Detection Limit:

Muscle - 0.3 ppb; Honey - 0.4 ppb; Milk - 3 ppb; Milk powder - 6 ppb; Eggs - 3 ppb.

Cross Reactivity:

Enrofloxacin - 100%, Oxolinic acid - 28%, Levofloxacin - 10%, Lomefloxacin - 4%, Marbofloxacin - 4%, Sarafloxacin - 2%

Sample Recovery rate:

85%±15%.

Storage:

2-8°C for 6 months.

Expiry:

See Kit Label

2. Storage

Store the kit at 2~8°C. Do not freeze any test kit components.

Return any unused microwells to their original foil bag and reseal them together with the desiccant provided and further store at 2 - 8°C.

3. Test Principle

This kit uses a Competitive-ELISA method. It can detect Enrofloxacin (ENR) in samples, such as honey, muscle, milk, etc. This kit is composed of ELISA Microtiter plate, HRP conjugate, antibody working solution, standard and other supplementary reagents. The microtiter plate in this kit has been pre-coated with coupled antigen. During the reaction, ENR in the samples or standard competes with coupled antigen on the solid phase supporter for sites of anti-ENR antibody. Then Horseradish Peroxidase (HRP) conjugate is added to each microtiter plate well, and TMB substrate is added for color development. There is a negative correlation between the OD value of samples and the concentration of ENR. The concentration of ENR in the samples can be calculated by comparing the OD of the samples to the standard curve.

4. Kit Contents

Each kit contains reagents for 96 assays including:

No.	Component	96-WellKit
1	ELISA Microtiter plate	96 wells
2	Standards	1mL each (0 ppb, 0.1 ppb, 0.3 ppb, 0.9 ppb, 2.7 ppb, 8.1 ppb)
3	HRP Conjugate	5.5 mL
4	Antibody Working Solution	5.5 mL
5	Substrate Reagent A	6 mL
6	Substrate Reagent B	6 mL
7	Stop Solution	6 mL
8	20xConcentrated Wash Buffer	40 mL
9	5xReconstitution Buffer	50 mL
10	Plate Sealer	3 pieces
11	Sealed Bag	1 piece
12	Manual	1 copy

Note: All reagent bottle caps must be tightened to prevent evaporation and microbial pollution.

Additional materials required:

Other materials required but not supplied

- **Instruments:** Microplate reader, Printer, Homogenizer, Nitrogen evaporators, Water bath, Vortex mixer, Centrifuge, Graduated pipette, Balance (sensitivity 0.01 g).
- **Micropipette:** Single channel (20-200 µL, 100-1000 µL), Multichannel (30-300 µL).
- **Reagents:** Anhydrous acetonitrile, N-hexane, Concentrated HCl, Dichloromethane

5. Experimental Preparation

Bring all reagents and samples to room temperature before use.

Open the microplate reader in advance, preheat the instrument, and set the testing parameters.

1. Sample pre-treatment Notice:

Experimental apparatus should be clean, and the pipette should be disposable to avoid cross-contamination during the experiment.

2. Solution preparation

Please prepare solution according to the number of samples. Don't use up all components in the kit at once!

Solution 1: 0.15 M HCl Solution

Add 5 mL of **Concentrated HCl** to 400 mL with deionized water, mix fully.

Solution 2: Sample Extraction Solution (for livestock, fish, shrimp, honey sample)

Add 10 mL of **0.15 M HCl Solution** (Solution 1) to 90mL of **Anhydrous acetonitrile**, mix fully.

Solution 3: Reconstitution Buffer

Dilute the **5xReconstitution Buffer** with deionized water.
(5xReconstitution Buffer (V): Deionized water (V)=1:4). The reconstitution buffer can be store at 4°C for a month.

Solution 4: Wash Buffer

Dilute **20xConcentrated Wash Buffer** with deionized water.
(20xConcentrated Wash Buffer (V): Deionized water (V) = 1:19).

3. Sample pre-treatment procedure

Targets may be distributed unevenly, resulting in no detection. To avoid this, ensure to take sufficient samples when sampling.

3.1 Pre-treatment of muscle (livestock, fish, shrimp) sample:

1. Weigh 2 ± 0.05 g of muscle homogenate into a 50 mL centrifuge tube.
2. Add 8 mL of **Sample Extraction Solution** (Solution 2) and vortex for 5 min. Centrifuge at 4000 r/min for 10 min at room temperature.
3. Remove 2 mL of the clear upper organic layer solution to a clean and dry glass tube, dry at 50-60°C. with nitrogen evaporators or water bath.
4. Add 1 mL of **N-hexane** and vortex for 2 min. Then add 1 mL of **Reconstitution Buffer** (Solution 3) and vortex for 30s to mix fully. Centrifuge for 5 min at 4000 r/min at room temperature.
5. Remove the N-hexane upper layer, take 50 μ L of the lower water layer solution for analysis.

Note: Sample dilution factor: 2, detection limit: 0.3 ppb

3.2 Pre-treatment of honey sample:

1. Weigh 1 ± 0.05 g of honey into a 50 mL centrifuge tube, add 6 mL of **Sample Extraction Solution** (Solution 2) and vortex for 5 min to ensure thoroughly dissolved.

2. Add 3 mL of **Reconstitution Buffer** (Solution 3) and 11 mL of **Dichloromethane**, vortex for 5 min. Then centrifuge at 4000 r/min for 5 min at room temperature.
3. Remove the supernatant and transfer 8 mL of the under layer organic solution to a dry tube. Dry at 50-60°C with nitrogen evaporators or water bath.
4. Dissolve the dry residue with 1 mL of **Reconstitution Buffer** (Solution 3). Add 1 mL of **N-hexane** and vortex for 30s. Centrifuge for 5 min at 3000 r/min at room temperature.
5. Remove the N-hexane upper layer, take 50 μ L of the lower layer solution for analysis.

Note: Sample dilution factor: 2, detection limit: 0.4 ppb

3.3 Pre-treatment of milk sample:

1. Dilute the milk with **Reconstitution Buffer** (Solution 3) for 20 times (e.g., add 25 μ L of milk into 475 μ L of Reconstitution Buffer), vortex for 1 min to dissolve it fully.
2. Take 50 μ L for analysis.

Note: Sample dilution factor: 20, detection limit: 3 ppb

3.4 Pre-treatment of milk powder sample:

1. Weigh 0.5 ± 0.02 g of homogenate sample into a 10 mL centrifuge tube, add 5 mL of deionized water and vortex to dissolve it fully.
2. Mix 100 μ L of sample solution with 400 μ L of **Reconstitution Buffer** (Solution 3). Vortex for 1 min.
3. Take 50 μ L for analysis.

Note: Sample dilution factor: 50, detection limit: 6 ppb

3.5 Pre-treatment of eggs sample:

1. Weigh 1 ± 0.02 of homogenate egg into a 10 mL centrifuge tube, add 5 mL of deionized water and vortex to dissolve it fully.
2. Mix 100 μ L of sample solution with 400 μ L of **Reconstitution Buffer** (Solution 3). Vortex for 1 min.
3. Take 50 μ L for analysis.

Note: Sample dilution factor: 30, detection limit: 3 ppb

6. Assay Procedure

Bring all reagents and samples to room temperature before use. All the reagents should be mixed thoroughly by gently swirling before pipetting. Avoid foaming. The unused ELISA Microtiter plate should be sealed as soon as possible and stored at 2~8°C.

1. **Number:** number the sample and standard in order (multiple well), and keep a record of standard wells and sample wells. **Standard and Samples need test in duplicate.**
2. **Add Sample:** add 50 μ L of **Standard or Sample** per well, then add 50 μ L of **HRP Conjugate** to each well. Add 50 μ L of **Antibody Working Solution**. Gently vortex for 5s to mix thoroughly and cover the plate with plate sealer. Incubate at 25°C for 45 min away from direct sunlight.
3. **Wash:** uncover the sealer carefully, remove the liquid in each well. Immediately add 300 μ L of **Wash Buffer** (Solution 4) to each well and wash. Repeat the wash procedure for 5 times, 30s intervals/time. Invert the plate and pat it against absorbent paper (If bubbles exist in the wells, clean tips can be used to prick them).
4. **Colour Development:** add 50 μ L of **Substrate Reagent A** to each well, and then add 50 μ L of **Substrate Reagent B**. Gently vortex for 5s to mix thoroughly. Incubate 25°C for 15 min away from direct sunlight
5. **Stop Reaction:** add 50 μ L of **Stop Solution** to each well, vortex gently to mix thoroughly.
6. **OD Measurement:** determine the optical density (OD value) of each well at 450 nm (reference wavelength 630 nm) with a microplate reader. This step should be finished in 10 min after stop reaction.

7. Data Analysis

1. **Absorbance (%) = $A/A_0 \times 100\%$**

A: Average absorbance of standard or sample

A_0 : Average absorbance of 0 ppb Standard

2. **Drawing and calculation of standard curve**

Create a standard curve by plotting the absorbance percentage of each standard on the y-axis against the log concentration on the x-axis to draw a semi-logarithmic plot. Add average absorbance value of sample to standard curve to get corresponding concentration. **If samples have been diluted, the concentration calculated from the standard curve must be multiplied by the dilution factor.**

For this kit, it is more convenient to use professional analysis form for accurate and fast analysis of batch samples.

8. Notes

1. The overall OD value will be lower when reagents have not been brought to room temperature before use or room temperature is below 25°C.
2. If the wells turn dry during the washing procedure, it will lead to bad linear standard curve and poor repeatability. Operate the next step immediately after wash.
3. Mix thoroughly and wash the plate completely. The consistency of wash procedure can strongly affect the reproducibility of this ELISA kit.
4. ELISA Microtiter plate should be covered by plate sealer. Avoid the kit to strong light.
5. **Each reagent is optimized for use in the FSES0024. Do not substitute reagents from any other manufacturer into the test kit. Do not combine reagents from other FSES0024 with different lot numbers.**
6. Substrate Reagent should be abandoned if it turns blue colour. When OD value of standard (concentration: 0) < 0.5 unit ($A_{450nm} < 0.5$), it indicates the reagents are deteriorated.
7. Stop solution is caustic, avoid contact with skin and eyes.
8. As the OD values of the standard curve may vary according to the conditions of the actual assay performance (e.g. operator, pipetting technique, washing technique or temperature effects), the operator should establish a standard curve for each test.
9. Even the same operator might get different results in two separate experiments. In order to get reproducible results, the operation of every step in the assay should be controlled.
10. If the samples are not indicated in the manual, a preliminary experiment to determine the validity of the kit is necessary.
11. The kit is used for rapid screening of actual samples. If the test result is positive, the instrument method such as HPLC, LC/MS, etc. can be used for quantitative confirmation.

Assay Genie 100% money-back guarantee!

If you are not satisfied with the quality of our products and our technical team cannot resolve your problem, we will give you 100% of your money back.

Contact Details



Email: info@AsssayGenie.com

Web: www.AssayGenie.com